



SILEX CLICKSHOW HDMI BUTTON UPDATE

Silex ClickShow button V1.0.9

To update your ClickShow HDMI Button, download the latest software version (client.tar.bz2) and the installer (pairupdate.exe) from the following link: <https://bit.ly/2lDxg4w>

Plug the USB cable of the HDMI button into your laptop and open pairupdate.exe. Click on upgrade and choose the software update file: “client.tar.bz2”, then click on ‘Update’.

A message will appear on your screen, indicating the update progress at the end of which you can unplug the button.

During the update, the light indicator on the button will be purple. Once the update is over, the light indicator will change back from purple to blue.

After updating a button, you need to pair it with the base unit

To verify that your button was successfully updated, you can plug it into your laptop, and run ‘pairupdate.exe’ to see the current software version installed on your button.