



# SILEX CLICKSHOW R101 UPGRADE

## Silex ClickShow R101 V3.2.3C

To upgrade your ClickShow device, download the latest software version first. Every software upgrade includes a Kernel version and an OS version.

Click on the following link to download both the latest Kernel and OS version :

<https://bit.ly/302itPT>

The Kernel version name looks like this: ulmage-2C.bin

The OS version name looks like this: rootfs-2C-ESHOW.jffs2

You can upgrade your ClickShow system via USB or via the Configurator as explained in the [ClickShow R101 Users Guide](#). If you choose to upgrade via the configurator, you should upgrade the Kernel version first. After the system reboot, upgrade the OS version.